

Differential Pressure Transmitters

A practical guide to differential pressure transmitters, covering the reader intent, the relationship to differential pressure transmitters, key evaluation criteria, common risks, and the information the intended project audience should confirm before taking the next step.



levelmeter.org
Main topic: Main Page
<https://www.level-meters.com/>

Differential pressure transmitters (DP transmitters) are among the most versatile and widely utilized instruments in industrial process control. While they are frequently associated with flow measurement via primary elements like orifice plates, their role in level measurement is equally critical, particularly in pressurized vessels and complex chemical processing environments. This guide examines the engineering principles, selection criteria, and installation requirements for differential pressure transmitters to assist engineers in optimizing their level measurement strategies.

Understanding the Measurement Principle of Differential Pressure Transmitters

The fundamental principle behind using differential pressure transmitters for level measurement is hydrostatic pressure. According to Pascal's Law, the pressure exerted by a static liquid column is proportional to its height and its density. The mathematical relationship is expressed as:

$$P = \rho \times g \times h$$

Where:

P is the hydrostatic pressure (typically measured in Pascals or bar).

ρ (rho) is the density of the liquid (kg/m³).

g is the acceleration due to gravity (approximately 9.81 m/s²).

h is the height of the liquid column (meters).

A differential pressure transmitter features two sensing ports: a High-Pressure (HP) side and a Low-Pressure (LP) side. The device measures the difference in pressure between these two points and converts it into an electrical signal, typically a 4-20mA HART, Foundation Fieldbus, or Profibus output.

In the context of level measurement, the transmitter is usually mounted at or below the minimum liquid level (the zero point). The HP side is connected to the bottom of the tank to sense the total pressure (liquid head plus any vapor space pressure). The LP side connection depends on whether the tank is open to the atmosphere or pressurized.

Applications in Level Measurement: Open vs. Closed Tanks

The configuration of differential pressure transmitters varies significantly based on the vessel type. Understanding these configurations is essential for accurate calibration and reliable performance.

Open (Vented) Tanks

In an open tank, the surface of the liquid is exposed to atmospheric pressure. To measure the level, the HP side of the DP transmitter is connected to the bottom of the vessel, while the LP side is vented to the atmosphere. Since both the top of the liquid and the LP side of the transmitter experience the same atmospheric pressure, the pressures cancel each other out. The transmitter effectively measures only the hydrostatic pressure exerted by the liquid height.

Closed (Pressurized) Tanks

In closed systems, such as boilers or chemical reactors, the space above the liquid is often filled with pressurized gas or vapor. If an open-vented transmitter were used, the vapor pressure would add to the liquid head pressure, causing a massive error in level reading.

To compensate for this, the LP side of the DP transmitter is connected to the top of the vessel (the vapor space). This ensures that the vapor pressure is applied to both sides of the sensing diaphragm. The transmitter subtracts the vapor pressure from the total pressure at the bottom, leaving only the pressure generated by the liquid column height.

Impulse Lines and Remote Seals

The method of connecting the transmitter to the process is a critical engineering decision. There are two primary methods: impulse piping and remote diaphragm seals.

| Impulse Piping (Wet and Dry Legs)

Impulse lines are small-diameter pipes or tubes that carry the process pressure to the transmitter.

Dry Leg: Used when the gas in the vapor space does not condense at ambient temperatures. The LP impulse line remains filled with gas.

Wet Leg: Used when the vapor is likely to condense (e.g., steam). The LP line is intentionally filled with a reference liquid (often the process fluid or a glycol mix) to prevent erratic readings caused by random condensation. This requires "Zero Elevation" during calibration to account for the constant pressure of the liquid-filled leg.

| Remote Diaphragm Seals

In many modern B2B applications, remote seals are preferred over impulse lines. These consist of a flexible diaphragm connected to the transmitter via a fluid-filled capillary tube. Remote seals are recommended when:

The process fluid is highly corrosive and could damage the transmitter internals.

The fluid contains solids that might plug impulse lines.

The process temperature exceeds the transmitter's operating limits.

The fluid is hygienic (food/pharmaceutical) and requires a flush-mount connection to avoid stagnant pockets.

| Critical Selection Criteria for Industrial Applications

Selecting the correct differential pressure transmitters requires a detailed analysis of the process conditions. Engineers should evaluate the following factors:

| 1. Pressure Range and Turndown Ratio

The transmitter must be capable of measuring the maximum hydrostatic head expected. However, it is also important to consider the "turndown ratio"—the ratio between the maximum range and the minimum span the device can measure while maintaining accuracy. High-quality instruments from manufacturers like Welk offer high turndown ratios, allowing one model to be used across various tank sizes.

| 2. Wetted Materials

The sensing diaphragm is the only part of the transmitter in direct contact with the process (unless using remote seals). Common materials include:

316L Stainless Steel: Standard for water and non-corrosive chemicals.

Hastelloy C-276: For aggressive acids and chlorides.

Tantalum: For highly corrosive chemical service.

Monel: Used in hydrofluoric acid or seawater applications.

| 3. Accuracy and Stability

For inventory control and custody transfer, high-precision transmitters with accuracies of $\pm 0.04\%$ or better are required. For simple process control or pump protection, a standard accuracy of $\pm 0.1\%$ or $\pm 0.2\%$ is usually sufficient. Long-term stability (the ability of the device to maintain calibration over years) is also a key factor in reducing maintenance costs.

4. Environmental Ratings

Industrial environments often involve extreme temperatures, humidity, and potential explosive atmospheres. Transmitters should carry appropriate ingress protection (IP66/67) and hazardous area certifications (ATEX, IECEx, or FM) if applicable.

Practical Selection Table

Application Feature	Recommended Configuration	Key Consideration
Clean Water (Open Tank)	Direct Mount, Vented LP	Cost-effective, simple installation.
Steam Boiler (Closed Tank)	Wet Leg or Remote Seal	Must account for condensate in LP line.
Corrosive Acids	Remote Diaphragm Seal (Tantalum/Hastelloy)	Protects transmitter from chemical attack.
Hygienic Food Processing	Flush Diaphragm Remote Seal	Eliminates bacteria growth points.
Slurries/High Viscosity	Large Diameter Remote Seal	Prevents clogging of the sensing port.

Installation Guidelines and Best Practices

Proper installation is as important as the device selection itself. Even the most accurate differential pressure transmitters will provide false data if installed incorrectly.

1. Mounting Position: The transmitter should ideally be mounted below the HP tap to allow any entrained gas bubbles in the impulse line to rise back into the tank. If mounted above the tap, the lines must be sloped, and air vent valves must be installed.

2. **Manifold Valves:** Always use a 3-valve or 5-valve manifold. This allows the transmitter to be isolated from the process for maintenance or zero-checking without shutting down the entire system. The equalizing valve on the manifold is essential for protecting the diaphragm from over-pressure during startup.

3. **Temperature Effects:** If using capillaries (remote seals), ensure that both capillaries are the same length and are routed together. This ensures that any ambient temperature changes affect both the HP and LP sides equally, canceling out the error.

4. **Zero Calibration:** Once installed and filled (if using wet legs), the transmitter must be zeroed at the actual process site to account for the weight of the liquid in the impulse lines or capillaries.

| Limitations and Operational Risks

While highly reliable, differential pressure transmitters have specific limitations that engineers must manage:

Density Sensitivity: Since the measurement is based on $P = \rho gh$, any change in the liquid density (ρ) will result in a level error. Density changes are usually caused by temperature fluctuations. In applications where temperature varies significantly, a temperature-compensated system or a different technology (like radar) may be required.

Vapor Space Variations: In closed tanks, if the vapor density becomes significant (e.g., high-pressure CO₂), it can exert its own hydrostatic head on the LP side, leading to measurement errors.

Mechanical Damage: The sensing diaphragms are extremely thin (often 0.05mm to 0.1mm). They can be easily damaged by pressure spikes (water hammer) or by personnel poking the diaphragm during cleaning.

| Frequently Asked Questions (FAQs)

Q: How often should a DP transmitter be calibrated?

A: Most modern digital transmitters are stable for 2 to 5 years. However, in critical safety applications or highly corrosive environments, annual verification is recommended.

Q: Can a DP transmitter measure the level of two different liquids in the same tank (Interface Level)?

A: Yes. If the transmitter is always submerged in the liquids, it can measure the interface between a heavier liquid (e.g., water) and a lighter liquid (e.g., oil), provided the total level remains above the top tap.

Q: What is the difference between "Zero Suppression" and "Zero Elevation"?

A: Zero suppression is used when the transmitter is mounted below the tank bottom, and the impulse line is dry. Zero elevation is used when the transmitter has a "wet leg" (the LP line is filled with liquid), which creates a constant pressure that must be subtracted from the reading.

| Conclusion and Next Steps

Differential pressure transmitters remain a cornerstone of industrial level measurement due to their proven reliability and adaptability. By understanding the relationship between hydrostatic pressure and liquid height, and by carefully selecting materials and installation methods, process engineers can achieve highly accurate results even in challenging environments. For those seeking specific product specifications or technical support for level measurement projects, you can Review product options and application support on our Main Page to find the ideal solution for your facility's requirements.

When evaluating your next installation, ensure that you have confirmed the fluid density, maximum operating pressure, and chemical compatibility to ensure the longevity and accuracy of your instrumentation.