


# Radar Level Transmitters

A practical guide to radar level transmitters, covering the reader intent, the relationship to radar level transmitters, key evaluation criteria, common risks, and the information the intended project audience should confirm before taking the next step.



levelmeter.org  
Main topic: Main Page  
<https://www.level-meters.com/>

In the landscape of industrial automation, radar level transmitters have emerged as the gold standard for non-contact level measurement. These instruments provide high-precision data even in the most challenging environments, where temperature fluctuations, high pressure, and heavy dust or steam render other technologies ineffective. As a professional manufacturer, Welk specializes in providing these advanced measurement solutions, ensuring that process industries—ranging from water treatment to chemical processing—can maintain operational efficiency and safety.

Understanding the nuances of radar technology is essential for engineers and procurement professionals. This guide explores the fundamental principles, selection criteria, and installation best practices for radar level transmitters to assist in technical decision-making.

## | Core Principles of Radar Level Measurement

Radar level measurement relies on the transmission of electromagnetic waves, typically in the microwave frequency range. Unlike ultrasonic sensors, which use sound waves and require a medium (air) to travel, radar waves travel at the speed of light and are largely unaffected by the atmosphere within a vessel. This makes them ideal for vacuum applications or environments with significant vapor density.

## | Time-of-Flight (ToF)

The underlying principle for most radar level transmitters is Time-of-Flight. The device emits a microwave signal from the antenna toward the surface of the medium. When the signal hits the medium, a portion of the energy is reflected back to the transmitter. The instrument measures the time interval between transmission and reception.

The distance (\$D\$) is calculated using the formula:

$$D = (c \times t) / 2$$

Where \$c\$ is the speed of light and \$t\$ is the measured time. Since the distance from the sensor to the tank bottom (the zero point) is known, the transmitter subtracts the measured distance to determine the actual level of the material.

## | Pulse Radar vs. FMCW

There are two primary methods for processing these signals in non-contact radar:

1. **Pulse Radar:** This technology sends out short microwave pulses and measures the time it takes for the pulse to return. It is known for its energy efficiency and is often used in battery-powered or loop-powered applications. It is effective for standard range measurements where extreme precision (sub-millimeter) is not the primary requirement.
2. **Frequency Modulated Continuous Wave (FMCW):** Instead of pulses, FMCW transmitters emit a continuous signal with a constantly changing frequency (a frequency sweep). The reflected signal is compared to the transmitted signal at that exact moment. The difference in frequency is directly proportional to the distance. FMCW is generally more accurate and provides better signal-to-noise ratios, making it the preferred choice for high-precision custody transfer or complex tank geometries.

## | Guided Wave Radar (GWR)

While non-contact radar transmits signals through the air, Guided Wave Radar (GWR) uses a physical probe (rod or cable) to direct the microwave signal to the liquid or solid surface. This technology is based on Time Domain Reflectometry (TDR). GWR is exceptionally stable because the signal is concentrated along the probe, making it immune to turbulence, foam, or internal tank obstructions that might interfere with a free-space radar beam.

## | Technical Selection Criteria

Selecting the right radar level transmitter requires a thorough analysis of the process medium and the vessel environment. The following factors are critical to ensuring long-term reliability.

## | Dielectric Constant ( $\epsilon_r$ )

The dielectric constant of the medium is the most significant factor in signal reflection. Materials with high dielectric constants (e.g., water,  $\epsilon_r \approx 80$ ) reflect signals very strongly. Conversely, hydrocarbons and oils often have low dielectric constants ( $\epsilon_r < 2.5$ ), meaning they reflect very little energy. For low-dielectric materials, high-sensitivity FMCW radars or Guided Wave Radar are typically required to ensure a reliable echo.

## | Frequency Selection (6GHz, 26GHz, 80GHz)

6GHz Radar: Excellent for applications involving heavy foam or steam, as the longer wavelength can penetrate these obstacles more effectively. However, it requires a larger antenna to maintain a narrow beam.

26GHz Radar: The industrial standard for many years. It offers a balance between beam focus and the ability to handle moderately dusty or steamy environments. It is widely used in chemical storage and water treatment.

80GHz Radar: The modern benchmark for high precision. The high frequency allows for an extremely narrow beam angle (often as low as  $3^\circ$ ). This is crucial for avoiding internal obstructions like agitators or heating coils and for measuring in narrow tanks or standpipes.

## | Selection Comparison Table

| Feature           | Pulse Radar (Non-contact) | FMCW Radar (Non-contact)          | Guided Wave Radar (GWR)       |
|-------------------|---------------------------|-----------------------------------|-------------------------------|
| Accuracy          | ±3mm to ±10mm             | ±1mm to ±2mm                      | ±2mm to ±5mm                  |
| Measurement Range | Up to 30m                 | Up to 120m                        | Up to 75m (cable)             |
| Pressure Limit    | Up to 4 MPa               | Up to 16 MPa                      | Up to 40 MPa                  |
| Temperature Limit | -40°C to +250°C           | -40°C to +450°C                   | -200°C to +450°C              |
| Best Use Case     | Simple liquid storage     | High-precision, long-range solids | Interface measurement, low DC |

## | Installation Considerations and Best Practices

Even the most advanced radar level transmitter will fail if installed incorrectly. Engineering teams must adhere to specific spatial requirements to ensure signal integrity.

## | Nozzle Geometry and Placement

The transmitter is typically mounted on a nozzle at the top of the tank. The nozzle should be as short as possible. If the nozzle is too long or narrow, it can create "ringing" or parasitic reflections that drown out the actual level signal. Ideally, the antenna should extend slightly past the bottom of the nozzle into the tank.

Key placement rules:

- Avoid the Center: Never mount a radar transmitter in the exact center of a dome-roof tank. This can cause multiple reflections to converge at the center, creating a false high-level signal.
- Wall Distance: Maintain a minimum distance from the tank wall (usually 1/6th of the tank diameter) to prevent the beam from reflecting off the wall or weld seams.
- Inflow Stream: Ensure the beam does not intersect the path of the falling product during filling, as this will cause significant signal noise.

## | Beam Angle and Obstructions

Every radar antenna has a beam angle. Any internal structure (ladders, pipes, agitators) that enters this beam will create a reflection. Modern transmitters like those found on our Main Page feature "False Echo Suppression" or "Echo Mapping." This allows the user to record the reflections from static internal structures while the tank is empty, telling the software to ignore those specific signals during operation.

## | Application-Specific Considerations

### | Solids and Powders

Measuring solids (grain, cement, plastic pellets) presents unique challenges. Unlike liquids, solids do not form a flat surface; they create cones of repose. This can deflect the radar signal away from the antenna. High-frequency 80GHz radar is preferred here because its narrow beam can be aimed at a specific area of the cone, and its high sensitivity can capture the diffuse reflections from uneven surfaces.

### | Corrosive Environments

In chemical processing, the transmitter is often exposed to aggressive vapors. For these applications, antennas should be encapsulated in PTFE (Polytetrafluoroethylene) or PFA. These materials provide a seamless, corrosion-resistant barrier that protects the sensitive electronics while allowing the microwave signal to pass through with minimal attenuation.

## | Interface Measurement

Guided Wave Radar is the primary choice for interface measurement (e.g., the boundary between oil and water). When the microwave signal hits the upper layer (oil), which has a low dielectric constant, part of the signal is reflected. The remaining signal continues through the oil and reflects off the lower layer (water), which has a much higher dielectric constant. This allows the transmitter to report both the total level and the interface level simultaneously.

## | Limitations and Risks

While radar is highly versatile, it is not a universal solution for every scenario. Professionals should be aware of the following limitations:

1. **Extremely Low Dielectric Media:** Materials with a dielectric constant below 1.4 (such as liquid nitrogen or certain liquefied gases) may not reflect enough energy for a standard non-contact radar. In these cases, a GWR with a coaxial probe or a bypass chamber is necessary.
2. **Heavy Foam:** While low-frequency radar can penetrate some foam, extremely dense, thick foam (like shaving cream consistency) can absorb the microwave signal entirely, leading to a "loss of echo" error.
3. **Conductive Dust Buildup:** If conductive dust or condensation builds up on the antenna surface, it can short-circuit the signal. While many Welk radar units feature self-cleaning designs or air purge connections, heavy buildup remains a maintenance risk.

## | Frequently Asked Questions (FAQ)

Q: Does the pressure inside the tank affect radar accuracy?

A: No. Microwave signals are electromagnetic and do not rely on air density. Radar operates accurately in full vacuum or at high pressures (e.g., 100 bar), provided the housing and seals are rated for the environment.

Q: Can radar measure through a plastic tank wall?

A: Yes. If the tank is made of a non-conductive material like polyethylene or fiberglass, the radar can be mounted outside the tank and measure through the top wall. This is a common solution for IBCs (Intermediate Bulk Containers) or chemical totes.

Q: What is the "Dead Zone" in radar measurement?

A: The dead zone (or blocking distance) is the area immediately below the antenna where the device cannot accurately measure. This is usually between 50mm and 300mm depending on the frequency and antenna type. Process levels should be kept below this zone.

Q: How does temperature affect the sensor?

A: The electronics have a standard operating range (usually  $-40^{\circ}\text{C}$  to  $+80^{\circ}\text{C}$ ). However, with specialized cooling fins or high-temperature antenna extensions, radar can measure materials at temperatures exceeding  $+450^{\circ}\text{C}$ .

## **| Conclusion**

Radar level transmitters represent a significant investment in process reliability and accuracy. By eliminating contact with the medium and providing immunity to most atmospheric conditions, they reduce maintenance costs and prevent process downtime. Whether utilizing the precision of 80GHz FMCW for narrow vessels or the stability of Guided Wave Radar for interface applications, selecting the correct technology is a matter of matching the physics of the instrument to the requirements of the environment.

For engineers looking to integrate these solutions into their automation systems, it is vital to confirm the dielectric constant of the medium and the physical constraints of the vessel. To explore a comprehensive range of industrial level measurement instruments, including radar, ultrasonic, and hydrostatic options, Review product options and application support to find the technical specifications that align with your project requirements.